

SoMachine V3.0

M238 PLC Diagnostic

 PLC_Diagnoctic.project


Example Guide

04/2012

Basic

Intermediate

Expert



EIO0000000901.00

The information provided in this documentation contains general descriptions and/or technical characteristics of the performance of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither Schneider Electric nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

No part of this document may be reproduced in any form or by any means, electronic or mechanical, including photocopying, without express written permission of Schneider Electric.

All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to help ensure compliance with documented system data, only the manufacturer should perform repairs to components.

When devices are used for applications with technical safety requirements, the relevant instructions must be followed.

Failure to use Schneider Electric software or approved software with our hardware products may result in injury, harm, or improper operating results.

Failure to observe this information can result in injury or equipment damage.


© 2011 Schneider Electric. All rights reserved.

Table of Contents



SAFETY INFORMATION	5
ABOUT THE BOOK	7
1. DESCRIPTION	13
1.1. Presentation	13
1.2. Functions Used in this Example	14
1.3. Hardware Installation	16
2. DESCRIPTION OF THE EXAMPLE'S CONTENT	17
3. CREATION OF THE PROJECT	18
4. EVENT TASK CREATION AND CONFIGURATION	20
5. WIRING THE CONTROLLER'S I0 FAST INPUT	24
6. LIBRARY MANAGER	25
7. CFC, LD, OR ST PROGRAM	26
7.1. CFC Program	27
7.2. LD Program	34
7.3. ST Program	45
8. RUNNING THE EXAMPLE	48
8.1. MAST Task Configuration	48
8.2. Downloading the Example to the Controller	50
8.3. Running the Example on the Controller	53

Safety Information



Important Information

NOTICE

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a Danger or Warning safety label indicates that an electrical hazard exists, which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

DANGER

DANGER indicates an imminently hazardous situation which, if not avoided, **will result in** death or serious injury.

WARNING

WARNING indicates a potentially hazardous situation which, if not avoided, **can result in** death or serious injury.

CAUTION

CAUTION indicates a potentially hazardous situation which, if not avoided, **can result in** minor or moderate injury.

CAUTION

CAUTION, used without the safety alert symbol, indicates a potentially hazardous situation which, if not avoided, **can result in** equipment damage.

PLEASE NOTE

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction and operation of electrical equipment and the installation, and has received safety training to recognize and avoid the hazards involved.

About the Book



At a Glance

Document Scope

This document describes one of the SoMachine examples.

Since the example described in this document is intended for learning purposes only, it must not be run, nor tested, on products that are part of a machine or process.

Validity Note

This document has been updated with the release of SoMachine V3.0.

The technical characteristics of the device(s) described in this manual also appear online. To access this information online:

Step	Action
1	Go to <i>www.schneider-electric.com</i>
2	In the Search box on the home page, type a model number. Do not type any blank spaces in the model number. To get information on a grouping of similar modules, you can use the characters ** ; do not use dots or xx's.
3	Under All , click Products → Product Datasheets and select the model number that interests you.
4	To save or print a data sheet as a .pdf file, click Export to PDF .

The characteristics presented in this manual should be the same as those that appear online. In line with our policy of constant improvement we may revise content over time to improve clarity and accuracy. In the event that you see a difference between the manual and online information, use the online information as your reference.

Related Documents

Title of Documentation	Reference Number
Modicon M238 Logic Controller Hardware Guide	EIO0000000016 (ENG); EIO0000000017 (FRE); EIO0000000018 (GER); EIO0000000019 (SPA); EIO0000000020 (ITA); EIO0000000021 (CHS)

Title of Documentation	Reference Number
M238 ExecLoader User Guide	EIO0000000374 (ENG); EIO0000000737 (FRE); EIO0000000738 (GER); EIO0000000739 (SPA); EIO0000000740 (ITA); EIO0000000741 (CHS)
Modicon M238 Logic Controller Programming Guide	EIO0000000384 (ENG); EIO0000000385 (FRE); EIO0000000386 (GER); EIO0000000387 (ITA); EIO0000000388 (SPA); EIO0000000389 (CHS)
Modicon M238 Logic Controller System Functions and Variables M238 PLCSystem Library Guide	EIO0000000364 (ENG); EIO0000000757 (FRE); EIO0000000758 (GER); EIO0000000759 (SPA); EIO0000000760 (ITA); EIO0000000761 (CHS)
SoMachine V3.0 PLC Time Example Guide	EIO0000000902 (ENG)

Product Related Information

This document and its related SoMachine project file focus on specific Functions and Function Blocks of the Schneider libraries provided with SoMachine, and on specific features available in SoMachine if these features are related to these libraries. They are intended to help you developing, testing, commissioning, and integrating applicative software of your own design on control systems.

It is intended for new SoMachine users who already have some degree of expertise in the design and programming of control systems.

<p>⚠ WARNING</p> <p>UNINTENDED EQUIPMENT OPERATION</p> <ul style="list-style-type: none"> ● Only use software approved by Schneider Electric for use with this equipment. ● Update your application program every time you change the physical hardware configuration. <p>Failure to follow these instructions can result in death, serious injury, or equipment damage.</p>

⚠ WARNING**LOSS OF CONTROL**

- The designer of any control scheme must consider the potential failure modes of control paths and, for certain critical control functions, provide a means to achieve a safe state during and after a path failure. Examples of critical control functions are emergency stop and overtravel stop, power outage and restart.
- Separate or redundant control paths must be provided for critical control functions.
- System control paths may include communication links. Consideration must be given to the implications of unanticipated transmission delays or failures of the link.
- Observe all accident prevention regulations and local safety guidelines.¹
- Each implementation of this equipment must be individually and thoroughly tested for proper operation before being placed into service.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

¹ For additional information, refer to NEMA ICS 1.1 (latest edition), "Safety Guidelines for the Application, Installation, and Maintenance of Solid State Control" and to NEMA ICS 7.1 (latest edition), "Safety Standards for Construction and Guide for Selection, Installation and Operation of Adjustable-Speed Drive Systems" or their equivalent governing your particular location.

Before You Begin

The products specified in this document have been tested under actual service conditions. Of course, your specific application requirements may be different from those assumed for this and any related examples described herein. In that case, you will have to adapt the information provided in this and other related documents to your particular needs. To do so, you will need to consult the specific product documentation of the hardware and/or software components that you may add or substitute for any examples specified in this documentation. Pay particular attention and conform to any safety information, different electrical requirements and normative standards that would apply to your adaptation.

⚠ WARNING**REGULATORY INCOMPATIBILITY**

Be sure that all equipment applied and systems designed comply with all applicable local, regional and national regulations and standards.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

The use and application of the information contained herein require expertise in the design and programming of automated control systems. Only the user or integrator can be aware of all the conditions and factors present during installation and setup, operation, and maintenance of the machine or process, and can therefore determine the automation and associated equipment and the related safeties and interlocks which can be effectively and properly used. When selecting automation

and control equipment, and any other related equipment or software, for a particular application, the user or integrator must also consider any applicable local, regional or national standards and/or regulations.

Some of the major software functions and/or hardware components used in the proposed architectures and examples described in this document cannot be substituted without significantly compromising the performance of your application. Further, any such substitutions or alterations may completely invalidate any proposed architectures, descriptions, examples, instructions, wiring diagrams and/or compatibilities between the various hardware components and software functions specified herein and in related documentation. You must be aware of the consequences of any modifications, additions or substitutions. A residual risk, as defined by EN/ISO 12100-1, Article 5, will remain if:

- it is necessary to modify the recommended logic and if the added or modified components are not properly integrated in the control circuit.
- you do not follow the required standards applicable to the operation of the machine, or if the adjustments to and the maintenance of the machine are not properly made (it is essential to strictly follow the prescribed machine maintenance schedule).
- the devices connected to any safety outputs do not have mechanically-linked contacts.

CAUTION

EQUIPMENT INCOMPATIBILITY

Read and thoroughly understand all device and software documentation before attempting any component substitutions or other changes related to the application examples provided in this document.

Failure to follow these instructions can result in injury or equipment damage.

Start-up and Test

Before using electrical control and automation equipment after design and installation, the application and associated functional safety system must be subjected to a start-up test by qualified personnel to verify correct operation of the equipment. It is important that arrangements for such testing be made and that enough time is allowed to perform complete and satisfactory testing.

⚠ CAUTION**EQUIPMENT OPERATION HAZARD**

- Verify that all installation and set up procedures have been completed.
- Before operational tests are performed, remove all blocks or other temporary holding means used for shipment from all component devices.
- Remove tools, meters and debris from equipment.

Failure to follow these instructions can result in injury or equipment damage.

Verify that the completed system, including the functional safety system, is free from all short circuits and grounds, except those grounds installed according to local regulations. If high-potential voltage testing is necessary, follow the recommendations in equipment documentation to help prevent injury or equipment damage.

Operation and Adjustments

Regardless of the care exercised in the design and manufacture of equipment or in the selection and ratings of components, there are hazards that can be encountered if such equipment is improperly installed and operated.

In some applications, such as packaging machinery, additional operator protection such as point-of-operation guarding must be provided. This is necessary if the hands and other parts of the body are free to enter the pinch points or other hazardous areas where serious injury can occur. Software products alone cannot protect an operator from injury. For this reason, the software cannot be substituted for or take the place of point-of-operation protection.

⚠ WARNING**UNGUARDED MACHINERY CAN CAUSE SERIOUS INJURY**

- Do not use this software and related automation equipment on equipment which does not have point-of-operation protection.
- Do not reach into machinery during operation.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Ensure that appropriate safeties and mechanical/electrical interlocks related to point-of-operation protection have been installed and are operational before placing the equipment into service. All interlocks and safeties related to point-of-operation protection must be coordinated with the related automation equipment and software programming.

NOTE: Coordination of safeties and mechanical/electrical interlocks for point-of-operation protection is outside the scope of the examples and implementations suggested herein.

About the Book

It is sometimes possible to adjust the equipment incorrectly and this produce unsatisfactory or unsafe operation. Always use the manufacturer instructions as a guide to functional adjustments. Personnel who have access to these adjustments must be familiar with the equipment manufacturer instructions and the machinery used with the electrical equipment.

Only those operational adjustments actually required by the machine operator should be accessible to the operator. Access to other controls should be restricted to help prevent unauthorized changes in operating characteristics.

User Comments

We welcome your comments about this document. You can reach us by e-mail at techcomm@schneider-electric.com.

1. Description

1.1. Presentation

This example presents the system functions of the M238 logic controller. These functions are located in the **M238 PLCSystem** library.

The controller's program is created using SoMachine software.

In this example, these system functions are used to diagnose the status a M238 controller in normal operation mode.

Related SoMachine project: **PLC_Diagnoctic.project**

Supported SoMachine Languages: CFC IL
 ST FBD
 LD SFC

Key features: System functions of the M238 logic controller

Requirements: To use this example, the user must have:

- installed SoMachine V3.0 on a PC.



Note: Because system functions of the controller are used in this example's program, **do not run this example in SIMULATION mode.**

1. Description

1.2. Functions Used in this Example

The Functions used in this example are listed below, grouped by library:

- **M238 PLCSystem** library (Schneider Electric)

These system Functions are specific to each controller. In the case of some of these functions, each controller's **PLCSystem** library features its own versions of these functions; e.g. the **M238 PLCSystem** library has a **IsFirstMastColdCycle** Function Block that has the same purpose than the **HMI_IsFirstMastColdCycle** Function of the **XBT PLCSystem** library.


Function	Description	Location in the Input Assistant
GetBatteryLevel	Returns remaining power charge of the battery	Module Calls → {} SEC → Read
GetBootProjectStatus	Returns the boot project status	
GetEventsNumber	Returns the number of external events detected	
GetFirmwareVersion	Returns information about the firmware, the boot and the coprocessor versions	
GetHardwareVersion	Returns the hardware version	
GetLastStopCause	Returns the cause last stop	
GetLocalIOStatus	Returns the embedded I/O status	
GetPlcFault	Returns detected errors on the controller I/O	
GetRightBusStatus	Returns the status of the expansion bus	
GetSerialNumber	Returns the serial number of the controller	
GetShortCutStatus	Returns the short-circuit status on the embedded outputs	
IsFirstMastColdCycle	Indicates if cycle is the first MAST cold start cycle	
IsFirstMastCycle	Indicates if cycle is the first MAST start cycle	
IsFirstMastWarmCycle	Indicates if cycle is the first MAST warm start cycle	
InhibitBatLowLed	Disables or re-enables the low battery LED	Module Calls → {} SEC → Write
ResetEventsNumber	Resets events number	

Note: The other functions of the **M238 PLCSystem** library are used in the example described in the *SoMachine V3.0 PLC Time Example Guide*.

Please refer to the SoMachine online help.

Note: In the rest of this document, the former sentence instructs you to refer to the online help of SoMachine, accessible through its upper-right  help button.

Please refer to the SoMachine online help for detailed information on these Functions: Function description, Graphical representation, I/O Variables description, and more.



The screenshot shows the 'Online Help' window with the search results for 'GetBatteryLevel'. The search bar on the left contains 'GetBatteryLevel' and is highlighted with a red box. The main content area displays the function description, graphical representation, and I/O variables description for 'GetBatteryLevel'.

Function Description
 This function returns the remaining power charge of the external backup battery (in percent).
 For more information about internal and external batteries, refer to the [M238 Hardware Guide](#).
NOTE: The similar information is also available through the System Variable [PLC_R.i_wBatteryStatus](#)

Graphical Representation


IL and ST Representation
 To see the general representation in IL or ST language, refer to the chapter [Function and Function Block Representation](#).

I/O Variables Description
 The following table describes the output variable:

Output	Type	Comment

© 2010 Schneider Electric. All rights reserved.


Search Results for GetBatteryLevel - 3 topic(s) found

Title	Location
GetBatteryLevel: Returns Remaining Power Charge of the Battery	m238sys
M238 Read Functions	m238sys
Internal and External Backup Batteries	m238hw

To install these libraries in your own project, please refer to *Library Manager* (see page 25).

1.3. Hardware Installation

Required Devices



N°	Designation	Reference	Use or Description
1	SoMachine Software	MSD CHNLMUA	SoMachine Software, 1-station license, installed on a PC
2a	Terminal port/USB port cordset	TCS XCN AM UM3P	From the mini B USB port on the Modicon M238 base to the type A USB port on the PC terminal for programming and updating firmware; length: 3 m (10 ft)
2b	Programming cable	BMX XCA USB H018	Same as TCS XCN AM UM3P, but with two ground connections along the cable; length: 1.8 m (6 ft)
3	M238 controller	TM238	Compact base logic controller with 24 I/O (removable battery to be ordered separately: TSX PLP 01)

Please refer to the *Modicon M238 Logic Controller Hardware Guide* for the hardware setup of this device.

2. Description of the Example's Content


In SoMachine, the configuration of the example is made with the following device:

- **1 Logic Controller:** TM238LFDC24DT

The program of the M238 controller is made of the following specific items:


- **Library Manager:** List of the libraries linked to the programs of this example.
- **CFC program:** Contains the source code that uses the system functions for diagnosing the Logic Controller. This is the default program since it is called by the MAST task of the controller.
- **LD program:** Translation of the CFC program into LD language. To run this program on the controller, change the POU called by the MAST task of the controller from **PLC_Diag_CFC** to **PLC_Diag_LD**.
- **EVENT_PROGRAM_ST program:** This empty program, in ST language, is only intended to be run by the EVENT_TASK task.
- **ST program:** Translation of the CFC program into ST language. To run this program on the controller, change the POU called by the MAST task of the controller from **PLC_Diag_CFC** to **PLC_Diag_ST**.
- **Task Configuration:** The standard MAST task, cyclically called every 20ms, plus an EVENT_TASK task, triggered by the external event configured for the **I0** fast input.
- **Embedded Functions:** Configuration of an external event on the rising and falling edges of the **I0** fast input.


Example's content, visible in the **Devices** panel of the **Program** tab:



3. Creation of the Project

The steps listed in the following table describe how to create the SoMachine project, and how to set up the device(s) used in this example. No details are given here since it is assumed that you already know the Basic commands of SoMachine.


Step	Action
1	<p>In the Create new machine part of the Home tab, select Start with empty project to create a new SoMachine project.</p> <p>Give this new project the following name: PLC_Diagnostic.</p>
2	<p>In the Configuration tab, add a TM238LFDC24DT Logic Controller.</p>  <p>Note: Details on the selected controller are displayed in the Information section of SoMachine.</p> <p><u>SoMachine controller version:</u> Defines the version of the selected controller; it is displayed in the Information section of SoMachine.</p> <p><u>Target controller firmware version:</u> Defines the firmware version of your controller. This version is shown when you select your controller's node, as shown in <i>Downloading the Example to the Controller</i> (see page 51).</p> <p>For compatibility purposes between a SoMachine controller version and a target controller firmware version, only the first three numbers of a version must be identical. In the preceding picture, the 2.0.30.13 SoMachine controller version is compatible with any 2.0.30.00 target controller firmware version.</p> <p>For each controller model, SoMachine only presents the latest available version. If you check the <input checked="" type="checkbox"/> Display all versions (for expert only) option, SoMachine will list all supported controller firmware versions. However, a good practice consists in using the latest available version and updating the firmware of your controller, if required. Please refer to the <i>M238 ExecLoader User Guide</i>.</p>



Step	Action
3	<p>Rename this controller to M238_Controller.</p>  <p>Information</p> <p>Name: M238_Controller(TM238LFDC24DT) Vendor: Schneider Electric Version: 2.0.30.13 Order-#: TM238LFDC24DT</p> <p>Description Compact base controller - 24V DC, 6 normal inputs, 8 fast inputs, 4 fast outputs (100 kHz), 6 transistor outputs (0.5 A). Timer and calendar. CANopen embedded. Removable terminal blocks.</p>
4	Save your new project.

4. Event Task Creation and Configuration



The steps listed in the following table describe how to create and configure an **Event Task**. This task is required for testing the **GetEventsNumber** and **ResetEventsNumber** functions.



To trigger this **Event Task**, an external event is configured on the rising and falling edges of the **I0** fast input of the M238 controller.

Step	Action																																																																								
1	In the Configuration tab, double-click on the M238_Controller . This opens the Parameters configuration panel of this controller.																																																																								
2	In the left-hand panel: <ul style="list-style-type: none"> ➤ Select the Embedded Functions group. ➤ Select the IO item. 																																																																								
3	<p>In the I/O configuration tab, configure the I0 input as follows:</p>  <p>The screenshot shows the 'I/O Configuration' window for the 'M238_Controller'. The 'I/O Mapping' tab is active. A table lists parameters for the 'I0' input:</p> <table border="1"> <thead> <tr> <th>Parameter</th> <th>Type</th> <th>Value</th> <th>Default Value</th> <th>Unit</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Inputs</td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td> I0</td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td> Filter</td> <td>Enumeration of BYTE</td> <td>No</td> <td>No</td> <td>ms</td> <td>Filtering value reduces the effect of noise on a controller input</td> </tr> <tr> <td> Latch</td> <td>Enumeration of BYTE</td> <td>No</td> <td>No</td> <td></td> <td>Latching allows incoming pulses with amplitude width shorter than...</td> </tr> <tr> <td> Event</td> <td>Enumeration of BYTE</td> <td>Both edges</td> <td>No</td> <td></td> <td>Event detection</td> </tr> <tr> <td> Bounce Filter</td> <td>Enumeration of BYTE</td> <td>1.2</td> <td>0.004</td> <td>ms</td> <td>Filtering value reduces the effect of bounce on a controller input</td> </tr> <tr> <td> Run/Stop</td> <td>Enumeration of BYTE</td> <td>No</td> <td>No</td> <td></td> <td>Run/Stop input can be used to run or stop a program in the controller</td> </tr> <tr> <td> I1</td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td> I2</td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td> I3</td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td> I4</td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table> <p>To achieve this configuration, please follow these steps:</p> <ul style="list-style-type: none"> ➤ Double-click on the No value of the Inputs ▶ I0 ▶ Event parameter. ➤ In the drop-down list that appears, select Both edges. ➤ Click outside this new value, or press the ENTER key, to validate it. <p>Note: Because this input is configured in Both edges, any rising edge or falling edge on the I0 fast input will trigger an external event on the controller.</p> <ul style="list-style-type: none"> ➤ Double-click on the 0.004 value of the Inputs ▶ I0 ▶ Bounce Filter parameter. ➤ In the drop-down list that appears, select 1.2. ➤ Click outside this new value, or press the ENTER key, to validate it. <p>Note: This Bounce Filter parameter, whose value is expressed in milliseconds, represents the duration of the anti-bounce filter applied to this fast input.</p>	Parameter	Type	Value	Default Value	Unit	Description	Inputs						I0						Filter	Enumeration of BYTE	No	No	ms	Filtering value reduces the effect of noise on a controller input	Latch	Enumeration of BYTE	No	No		Latching allows incoming pulses with amplitude width shorter than...	Event	Enumeration of BYTE	Both edges	No		Event detection	Bounce Filter	Enumeration of BYTE	1.2	0.004	ms	Filtering value reduces the effect of bounce on a controller input	Run/Stop	Enumeration of BYTE	No	No		Run/Stop input can be used to run or stop a program in the controller	I1						I2						I3						I4					
Parameter	Type	Value	Default Value	Unit	Description																																																																				
Inputs																																																																									
I0																																																																									
Filter	Enumeration of BYTE	No	No	ms	Filtering value reduces the effect of noise on a controller input																																																																				
Latch	Enumeration of BYTE	No	No		Latching allows incoming pulses with amplitude width shorter than...																																																																				
Event	Enumeration of BYTE	Both edges	No		Event detection																																																																				
Bounce Filter	Enumeration of BYTE	1.2	0.004	ms	Filtering value reduces the effect of bounce on a controller input																																																																				
Run/Stop	Enumeration of BYTE	No	No		Run/Stop input can be used to run or stop a program in the controller																																																																				
I1																																																																									
I2																																																																									
I3																																																																									
I4																																																																									

Step	Action
4	<p>Click on the IO Summarize... button located in the lower right corner of the central panel.</p> <p>The IO Summary window that appears shows that the I0 input of the controller has been affected to an Event.</p> 
5	Click on OK to close the IO Summary window.
6	Go to the Devices panel of the Program tab.
7	<p>Create a new POU, in ST language, called EVENT_PROGRAM_ST.</p>  <p>Upon creation of this POU, it is automatically opened by SoMachine.</p> <p>Note: At first, this program is empty. In this example, it will remain empty because its only purpose consists in providing an Event Task with a program to run.</p>

4. Event Task Creation and Configuration


Step	Action
8	<p>Create a new task:</p> <ul style="list-style-type: none">➤ Expand the contents of the M238_Controller (TM238LFDC24DT) item.➤ Right-click on the Task Configuration item.➤ In the Add Object part of the contextual menu that appears, select the Task... command.  <p>➤ In the Add Task window that appears, write the Name of this new task: EVENT_TASK.</p> <p>➤ Click on OK to validate the creation of this new task.</p> 

Step	Action
9	Double-click on the EVENT_TASK task and configure it as follows:
	
To achieve this configuration, please follow these steps:	
<ul style="list-style-type: none"> ➤ Change the Type of this task from Cyclic to External. ➤ Check that the External event is equal to IO; if this not the case, change it to IO. Note: With this configuration, the EVENT_TASK task will be run each time the event configured for the IO fast input of the controller (see page 20) is triggered. ➤ Click on the Add POU command. 	
In the Input Assistant window that appears:	
<ul style="list-style-type: none"> ➤ Select the EVENT_PROGRAM_ST program. ➤ Click on OK. 	
	

5. Wiring the Controller's I0 Fast Input

Before wiring the controller's **I0** fast input, you must first refer to the *Modicon M238 Logic Controller Hardware Guide*.

The following diagram is an adaptation of the **Fast Input Wiring Diagram**, given in the *Modicon M238 Logic Controller Hardware Guide*, to the usage made by this example of the controller's fast inputs.




(1) Fast-blow fuse 0.5 A

In this diagram, the push-button wired to the **I0** fast input is used to generate pulses. Each rising or falling edge of these pulses will be transformed into an **I0** external event.

6. Library Manager

The steps listed in the following table describe how to add and/or check the list of the libraries linked to this example.

Step	Action																											
1	<p>Select the Program tab.</p> <p>In the Devices tree view, double-click on the Library Manager to open the list of the libraries linked to the Application software of this example.</p>																											
2	<p>Check that the M238 PLCSystem library is already linked, as shown below:</p>  <p>The screenshot shows the 'Library Manager' window with the following table of libraries:</p> <table border="1"> <thead> <tr> <th>Name</th> <th>Namespace</th> <th>Effective version</th> </tr> </thead> <tbody> <tr> <td>IoStandard, 3.4.1.0 (System)</td> <td>IoStandard</td> <td>3.4.1.0</td> </tr> <tr> <td>Standard, 3.4.1.0 (System)</td> <td>Standard</td> <td>3.4.1.0</td> </tr> <tr> <td>Util, 3.4.1.20 (System)</td> <td>Util</td> <td>3.4.1.20</td> </tr> <tr style="border: 2px solid red;"> <td>M238 PLCSystem, 1.0.1.14 (Schneider Electric)</td> <td>SEC</td> <td>1.0.1.14</td> </tr> <tr> <td>M238 Relocation Table, 1.0.0.3 (Schneider Electric)</td> <td>SEC_RELOC</td> <td>1.0.0.3</td> </tr> <tr> <td>M238 HSC, 1.0.1.5 (Schneider Electric)</td> <td>SEC_HSC</td> <td>1.0.1.5</td> </tr> <tr> <td>M238 PTPPWM, 1.0.1.5 (Schneider Electric)</td> <td>SEC_PTOPWM</td> <td>1.0.1.5</td> </tr> <tr> <td>PLCCommunication, 1.0.2.13 (Schneider Electric)</td> <td>SEN</td> <td>1.0.2.13</td> </tr> </tbody> </table> <p>The detailed view of the 'm238 plcsystem' library shows the following structure:</p> <ul style="list-style-type: none"> BOOT_PROJECT_STATUS DAY_OF_WEEK FIRMWARE_VERSION HOUR LOCAL_IO_GEN_STATUS LOCAL_IO_GET_STATUS MINUTE RIGHTBUS_GET_STATUS STOP_WHY PLC_RW <ul style="list-style-type: none"> Read <ul style="list-style-type: none"> GetBatteryLevel GetBootProjectStatus GetEventsNumber GetFirmwareVersion GetHardwareVersion GetLastStopCause GetLastStopTime GetLocalIOStatus GetPlcFault GetRightBusStatus GetSerialNumber GetShortCutStatus IsFirstMastColdCycle IsFirstMastCycle IsFirstMastWarmCycle SER_RW Write <ul style="list-style-type: none"> InhibitBatLowLed ResetEventsNumber SetRTCDrift 	Name	Namespace	Effective version	IoStandard, 3.4.1.0 (System)	IoStandard	3.4.1.0	Standard, 3.4.1.0 (System)	Standard	3.4.1.0	Util, 3.4.1.20 (System)	Util	3.4.1.20	M238 PLCSystem, 1.0.1.14 (Schneider Electric)	SEC	1.0.1.14	M238 Relocation Table, 1.0.0.3 (Schneider Electric)	SEC_RELOC	1.0.0.3	M238 HSC, 1.0.1.5 (Schneider Electric)	SEC_HSC	1.0.1.5	M238 PTPPWM, 1.0.1.5 (Schneider Electric)	SEC_PTOPWM	1.0.1.5	PLCCommunication, 1.0.2.13 (Schneider Electric)	SEN	1.0.2.13
Name	Namespace	Effective version																										
IoStandard, 3.4.1.0 (System)	IoStandard	3.4.1.0																										
Standard, 3.4.1.0 (System)	Standard	3.4.1.0																										
Util, 3.4.1.20 (System)	Util	3.4.1.20																										
M238 PLCSystem, 1.0.1.14 (Schneider Electric)	SEC	1.0.1.14																										
M238 Relocation Table, 1.0.0.3 (Schneider Electric)	SEC_RELOC	1.0.0.3																										
M238 HSC, 1.0.1.5 (Schneider Electric)	SEC_HSC	1.0.1.5																										
M238 PTPPWM, 1.0.1.5 (Schneider Electric)	SEC_PTOPWM	1.0.1.5																										
PLCCommunication, 1.0.2.13 (Schneider Electric)	SEN	1.0.2.13																										
<p>Note: This library is grayed to inform that it has been automatically linked to the program upon addition of the M238 Controller to the project and that it cannot be removed.</p>																												

7. CFC, LD, or ST Program

Each of the following three chapters describes how to create the program used in the example. Choose the language of your program (CFC, LD, or ST) and go to the corresponding chapter:


- CFC Program 27
- LD Program 34
- ST Program 45



You only need to write your SoMachine program in one of these three languages.



In addition, each of these three chapters begins with explanations on the difficulties you may face, if any, in the form of **optional steps**.

7.1. CFC Program


Before instructing you how to write down the CFC program used in this example, the following table presents optional steps that give you information on how to program in CFC language.

Step	Action
1	<p>Optional step</p> <p>How to add the EN/ENO pins on a Function Block</p> <p>In this example, these pins are used on three functions: IsFirstMastWarmCycle, IsFirstMastColdCycle, and ResetEventsNumber.</p> <p>This optional step indicates how to append the additional Boolean enable input EN and Boolean output ENO (Enable Out) to any Function or Function Block. These two pins are used to enable (TRUE) or disable (FALSE) the execution of the Functions or Function Blocks on which they are used. Please refer to the SoMachine online help: search for additional Boolean ENO.</p> <ul style="list-style-type: none"> ➤ Right-click, in your CFC program, on a Function (or a Function Block). ➤ In the contextual menu that appears, select the EN/ENO command.  <p>Note: If you want to remove these EN/ENO pins, select the EN/ENO command again.</p>


Step	Action
2	<p>Optional step</p> <p>How to use a Selector element to display structure components</p> <p>In this example, the Selector element is used to access the three components of a variable whose type is the FIRMWARE_VERSION structure: FwVersion, BootVersion, and AsicVersion.</p> <p>This optional step indicates how to use a Selector element. Its input is a variable whose type must be a structure. The number of its outputs depends on the number of components of this structure: the Selector element has one output per component of the input structure. Please refer to the SoMachine online help: search for Selector.</p> <p>In the following steps, a Selector element is used to access the various components of the structured output of the GetFirmwareVersion Function (output type = FIRMWARE_VERSION structure):</p> <ul style="list-style-type: none"> ➤ From the ToolBox panel, create a Selector element into the central worksheet.  <ul style="list-style-type: none"> ➤ Determine the name of the structure you want to use for this Selector element. In the given example, this element will be used with the GetFirmwareVersion output of the GetFirmwareVersion Function. The type of this output is a structure whose name is FIRMWARE_VERSION.  <ul style="list-style-type: none"> ➤ Click on the ??? of the Selector element. ➤ Click on the white button that appears next to the ???; this will display the Input Assistant. 

Step	Action
	<p>➤ In the Input Assistant, select the FIRMWARE_VERSION data type.</p>  <p>Note: The Documentation section displays details on the components of the selected data type.</p> <p>Note: As a general rule, a data type used by a Function (or a Function Block) is located in the very same library than the Function (or Function Block). In the given example, the GetFirmwareVersion Function and the FIRMWARE_VERSION data type, used by this Function, are both located in the M238 PLCSystem library.</p> <p>➤ Click on OK.</p> <p>➤ Press the ENTER key to validate this choice.</p>  <p>➤ Connect the Selector element's input to the GetFirmwareVersion output of the GetFirmwareVersion Function.</p> <p>Now, each component of the GetFirmwareVersion Function's structured output is available as one of the outputs of the Selector element.</p>

7. CFC, LD, or ST Program

Step	Action
3	<p>Creation of the POU: Create a new POU in CFC language, called PLC_Diag_CFC.</p>  <p>Upon creation of this POU, it is automatically opened by SoMachine.</p>


Step	Action
4	<p>CFC variables: In the upper part of the CFC editor, declare the following variables:</p> <pre> PROGRAM PLC_Diag_CFC VAR (*First Mast Cycle Functions*) q_xIsFirstMastCycle : BOOL; q_xIsFirstMastWarmCycle : BOOL; q_xIsFirstMastColdCycle : BOOL; (*Firmware Version Function*) q_FirmwareVersion : FIRMWARE_VERSION; v_dwFwVersion : DWORD; v_wBootVersion : WORD; v_wCoProcVersion : WORD; (*Hardware Version Function*) q_wHardwareVersion : WORD; (*Serial Number Function*) q_dwSerialNumber : DWORD; (*Battery Functions*) q_wBatteryLevel : WORD; i_xInhibitBatLowLed : BOOL := FALSE; q_wResultInhibitBattLed : WORD; (*Event Functions*) q_dwEventNumber : DWORD; v_xResetEventsNumber : BOOL := FALSE; q_xResetEventsNumber : BOOL; (*Last Stop Cause Function*) q_LastStopCause : STOP_WHY; (*Boot Project Status Function*) q_BootProjectStatus : BOOT_PROJECT_STATUS; (*Short-Circuit Status on Embedded Outputs Function*) q_wShortCutStatus : WORD; (*Expansion Bus Status Function*) i_ExpansionTested : RIGHTBUS_GET_STATUS; q_wRightBusStatusGen : WORD; q_wRightBusStatus : WORD; (*Controller I/O Generic Diagnostic Function*) q_wPlcFault : WORD; v_xErrorIOExpansionBus : BOOL; v_xErrorEmbeddedIO : BOOL; (*I/O Status Function*) q_IOStatus : LOCAL_IO_GEN_STATUS; END_VAR </pre>




Step	Action
	<p>The diagram illustrates the data flow of a CFC program. It consists of several function blocks and their connections:</p> <ul style="list-style-type: none"> Expansion Bus Status Function: Includes blocks for <code>RIGHTBUS_GET_STATUS.RIGHTBUS_GET_GEN_STATUS</code> (connected to <code>Mask</code> of <code>GetRightBusStatus</code> 30) and <code>RIGHTBUS_GET_STATUS.RIGHTBUS_GET_STATUS1</code> (connected to <code>i_ExpansionTested</code> 32). Expansion bus configuration diagnostic: Includes <code>GetRightBusStatus</code> 30, which outputs <code>q_wRightBusStatusGen</code> 31. Expansion bus Module 1 diagnostic: Includes <code>GetRightBusStatus</code> 33, which outputs <code>q_wRightBusStatus</code> 34. Controller I/O Generic Diagnostic Function: Includes <code>GetPlcFault</code> 35, which outputs <code>q_wPlcFault</code> 36. This block is further connected to <code>q_wPlcFault.0</code> (outputting <code>v_xErrorIOExpansionBus</code> 37) and <code>q_wPlcFault.1</code> (outputting <code>v_xErrorEmbeddedIO</code> 38). I/O Status Function: Includes <code>LOCAL_ID_GET_STATUS.LOCAL_ID_GET_GEN_STATUS</code> (connected to <code>Mode</code> of <code>GetLocalIOStatus</code> 39) and <code>GetLocalIOStatus</code> 39, which outputs <code>q_IDStatus</code> 40.
6	<p>Order By Data Flow</p> <p>When you have finished implementing this CFC program, perform the following steps to correctly set the execution order of its blocks:</p> <ul style="list-style-type: none"> ➤ Right-click on an empty spot of the central worksheet. ➤ In the Execution Order part of the contextual menu, execute the Order By Data Flow command. <p>The screenshot shows a contextual menu with the following options:</p> <ul style="list-style-type: none"> Cut Copy Paste Delete Select All Input Assistant... Edit Working Sheet... Negate EN/ENO Set/Reset Execution Order (highlighted) <ul style="list-style-type: none"> Send To Front Send To Back Move Up Move Down Set Execution Order... Order By Data Flow (highlighted by mouse cursor) Order By Topology Edit Parameters... Connect Selected Pins Reset Pins Remove Unused Pins


7.2. LD Program



Before instructing you how to write down the LD program used in this example, the following table presents optional steps that give you information on how to program in LD language.



Step	Action
1	<p>Optional step</p> <p>How to display titles and comments in LD language</p> <ul style="list-style-type: none"> ➤ Select the Options... command of the Tools menu. ➤ Select, in the Options window, the FBD, LD and IL editor section. ➤ If you wish to add a title and/or a comment for each LD network, check the <input checked="" type="checkbox"/> Show network title and/or the <input checked="" type="checkbox"/> Show network comment options, as shown below:  <p>The screenshot shows the 'Options' dialog box with the 'FBD, LD and IL editor' section selected. Under the 'View' tab, the following options are visible:</p> <ul style="list-style-type: none"> <input type="checkbox"/> Connect boxes with straight lines <input checked="" type="checkbox"/> Show network title <input checked="" type="checkbox"/> Show network comment <input type="checkbox"/> Show operand comment <input type="checkbox"/> Show symbol comment <input type="checkbox"/> Show symbol address <input checked="" type="checkbox"/> Show box icon <input type="checkbox"/> Fixed size for operands: <ul style="list-style-type: none"> Width of operand field: 23 characters Height of operand field: 1 lines Height of operand comment field: 1 lines Height of symbol comment field: 1 lines <p>Buttons for 'OK' and 'Cancel' are located at the bottom right of the dialog box.</p>



Step	Action
2	<p>Optional step</p> <p>How to add the EN/ENO pins on a Function Block</p> <p>In this example, these pins are used on three functions: IsFirstMastWarmCycle, IsFirstMastColdCycle, and ResetEventsNumber.</p> <p>This optional step indicates how to append the additional Boolean enable input EN and Boolean output ENO (Enable Out) to any Function or Function Block. These two pins are used to enable (TRUE) or disable (FALSE) the execution of the Functions or Function Blocks on which they are used. Please refer to the SoMachine online help: search for additional Boolean ENO.</p> <p>➤ In the View part of the FBD/LD/IL menu, select the View as function block diagram mode.</p>  <p>The screenshot shows the Siemens SoMachine software interface. The 'FBD/LD/IL' menu is open, and the 'View' option is selected. The 'View' submenu is displayed, showing three options: 'View as function block diagram' (Ctrl+1), 'View as ladder logic' (Ctrl+2), and 'View as instruction list' (Ctrl+3). A red circle and arrow highlight the 'View as function block diagram' option.</p>

7. CFC, LD, or ST Program


Step	Action
	<ul style="list-style-type: none">➤ Select, in your LD program, the LD network where you want to add a Function Block (or a Function).➤ In the FBD/LD/IL menu, execute the Insert Box with EN/ENO command. 

Step	Action																																	
	<ul style="list-style-type: none"> ➤ In the Input Assistant window that appears, select the Function blocks category, if you wish to add a Function Block, or the Module Calls category, if you wish to add a Function. ➤ Select the Function Block (or the Function) you wish to add in your program. <p>In the following picture, the ResetEventsNumber Function of the M238 PLCSystem library is selected. The location of this Function is given in <i>Functions Used in this Example</i> (see page 14):</p>  <table border="1" data-bbox="560 573 1382 853"> <thead> <tr> <th>Name</th> <th>Type</th> <th>Origin</th> </tr> </thead> <tbody> <tr> <td>Application</td> <td>Application</td> <td></td> </tr> <tr> <td>IoStandard</td> <td>Library</td> <td>iostandard, 3.4.1.0 (system)</td> </tr> <tr> <td>SEC</td> <td>Library</td> <td>m238.plcsystem, 1.0.1.14 (schneider electric)</td> </tr> <tr> <td> Read</td> <td></td> <td></td> </tr> <tr> <td> Write</td> <td></td> <td></td> </tr> <tr> <td> InhibitBatLowLed</td> <td>FUNCTION</td> <td>m238.plcsystem, 1.0.1.14 (schneider electric)</td> </tr> <tr> <td> ResetEventsNumber</td> <td>FUNCTION</td> <td>m238.plcsystem, 1.0.1.14 (schneider electric)</td> </tr> <tr> <td> SetRTCDrift</td> <td>FUNCTION</td> <td>m238.plcsystem, 1.0.1.14 (schneider electric)</td> </tr> <tr> <td>Standard</td> <td>Library</td> <td>standard, 3.4.1.0 (system)</td> </tr> <tr> <td>Util</td> <td>Library</td> <td>util, 3.4.1.20 (system)</td> </tr> </tbody> </table> <p><input checked="" type="checkbox"/> Insert with arguments <input checked="" type="checkbox"/> Structured view <input type="checkbox"/> Show documentation <input type="button" value="OK"/> <input type="button" value="Cancel"/></p>	Name	Type	Origin	Application	Application		IoStandard	Library	iostandard, 3.4.1.0 (system)	SEC	Library	m238.plcsystem, 1.0.1.14 (schneider electric)	Read			Write			InhibitBatLowLed	FUNCTION	m238.plcsystem, 1.0.1.14 (schneider electric)	ResetEventsNumber	FUNCTION	m238.plcsystem, 1.0.1.14 (schneider electric)	SetRTCDrift	FUNCTION	m238.plcsystem, 1.0.1.14 (schneider electric)	Standard	Library	standard, 3.4.1.0 (system)	Util	Library	util, 3.4.1.20 (system)
Name	Type	Origin																																
Application	Application																																	
IoStandard	Library	iostandard, 3.4.1.0 (system)																																
SEC	Library	m238.plcsystem, 1.0.1.14 (schneider electric)																																
Read																																		
Write																																		
InhibitBatLowLed	FUNCTION	m238.plcsystem, 1.0.1.14 (schneider electric)																																
ResetEventsNumber	FUNCTION	m238.plcsystem, 1.0.1.14 (schneider electric)																																
SetRTCDrift	FUNCTION	m238.plcsystem, 1.0.1.14 (schneider electric)																																
Standard	Library	standard, 3.4.1.0 (system)																																
Util	Library	util, 3.4.1.20 (system)																																
	<ul style="list-style-type: none"> ➤ Click on OK. <p>This adds the selected Function Block (or Function) to your program, with the two EN and ENO pins.</p> <ul style="list-style-type: none"> ➤ In the View part of the FBD/LD/IL menu, you can now select the View as ladder logic mode to return to the default view mode. 																																	

Step	Action
3	<p>Optional step</p> <p>How to use the Insert Empty Box Command</p> <p>Sometimes, the Empty Box created by the Insert Empty Box command does not work with a Function or Function Block.</p> <p>In this example, the Empty Box is not compatible with the GetRightBusStatus and the InhibitBatLowLed Functions.</p> <p>In this case, you must use the Insert Box command, instead of the Insert Empty Box command.</p> <p>Example: In the following picture, the GetRightBusStatus Function is rejected by an Empty Box; in this case, the Insert Box command must be used:</p>  <ul style="list-style-type: none"> ➤ Select, in your LD program, the LD network where you want to add a Function Block (or a Function). ➤ In the FBD/LD/IL menu, execute the Insert Box command. 


Step	Action
	<p>➤ In the Input Assistant window that appears, select the Function blocks category, if you wish to add a Function Block, or the Module Calls category, if you wish to add a Function.</p> <p>➤ Select the Function Block (or the Function) you wish to add in your program.</p> <p>In the following picture, the GetRightBusStatus Function of the M238 PLCSystem library is selected:</p>  <p>➤ Click on OK.</p> <p>This adds the selected Function Block (or Function) to your program.</p> 


7. CFC, LD, or ST Program

Step	Action
4	<p>Creation of the POU: Create a new POU in LD language, called PLC_Diag_LD.</p>  <p>Upon creation of this POU, it is automatically opened by SoMachine.</p>


Step	Action
5	<p>LD variables: In the upper part of the LD editor, declare the following variables:</p> <pre> PROGRAM PLC_Diag_LD VAR (*First Mast Cycle Functions*) q_xIsFirstMastCycle : BOOL; q_xIsFirstMastWarmCycle : BOOL; q_xIsFirstMastColdCycle : BOOL; (*Firmware Version Function*) q_FirmwareVersion : FIRMWARE_VERSION; v_dwFwVersion : DWORD; v_wBootVersion : WORD; v_wCoProcVersion : WORD; (*Hardware Version Function*) q_wHardwareVersion : WORD; (*Serial Number Function*) q_dwSerialNumber : DWORD; (*Battery Functions*) q_wBatteryLevel : WORD; i_xInhibitBatLowLed : BOOL := FALSE; q_wResultInhibitBattLed : WORD; (*Event Functions*) q_dwEventNumber : DWORD; v_xResetEventsNumber : BOOL := FALSE; q_xResetEventsNumber : BOOL; (*Last Stop Cause Function*) q_LastStopCause : STOP_WHY; (*Boot Project Status Function*) q_BootProjectStatus : BOOT_PROJECT_STATUS; (*Short-Circuit Status on Embedded Outputs Function*) q_wShortCutStatus : WORD; (*Expansion Bus Status Function*) i_ExpansionTested : RIGHTBUS_GET_STATUS; q_wRightBusStatusGen : WORD; q_wRightBusStatus : WORD; (*Controller I/O Generic Diagnostic Function*) q_wPlcFault : WORD; v_xErrorIOExpansionBus : BOOL; v_xErrorEmbeddedIO : BOOL; (*I/O Status Function*) q_IOStatus : LOCAL_IO_GEN_STATUS; END_VAR </pre>

7. CFC, LD, or ST Program






7. CFC, LD, or ST Program

Step	Action
	<p data-bbox="304 215 331 237">21</p> <p data-bbox="368 226 571 248"><i>I/O Status Function</i></p>  <p>The diagram shows a single normally open contact labeled 'LOCAL_IO_GET_STATUS.LOCAL_IO_GET_GEN_STATUS' connected to a coil labeled 'GETLOCALIOSTATUS'. The coil is connected to a normally open contact labeled 'q_IOStatus'.</p>

7.3. ST Program


Step	Action
1	<p>Creation of the POU: Create a new POU in ST language, called PLC_Diag_ST.</p>  <p>Upon creation of this POU, it is automatically opened by SoMachine.</p>

Step	Action
2	<p>ST variables: In the upper part of the ST editor, declare the following variables:</p> <pre> PROGRAM PLC_Diag_ST VAR (*First Mast Cycle Functions*) q_xIsFirstMastCycle : BOOL; q_xIsFirstMastWarmCycle : BOOL; q_xIsFirstMastColdCycle : BOOL; (*Firmware Version Function*) q_FirmwareVersion : FIRMWARE_VERSION; v_dwFwVersion : DWORD; v_wBootVersion : WORD; v_wCoProcVersion : WORD; (*Hardware Version Function*) q_wHardwareVersion : WORD; (*Serial Number Function*) q_dwSerialNumber : DWORD; (*Battery Functions*) q_wBatteryLevel : WORD; i_xInhibitBatLowLed : BOOL := FALSE; q_wResultInhibitBattLed : WORD; (*Event Functions*) q_dwEventNumber : DWORD; v_xResetEventsNumber : BOOL := FALSE; q_xResetEventsNumber : BOOL; (*Last Stop Cause Function*) q_LastStopCause : STOP_WHY; (*Boot Project Status Function*) q_BootProjectStatus : BOOT_PROJECT_STATUS; (*Short-Circuit Status on Embedded Outputs Function*) q_wShortCutStatus : WORD; (*Expansion Bus Status Function*) i_ExpansionTested : RIGHTBUS_GET_STATUS; q_wRightBusStatusGen : WORD; q_wRightBusStatus : WORD; (*Controller I/O Generic Diagnostic Function*) q_wPlcFault : WORD; v_xErrorIOExpansionBus : BOOL; v_xErrorEmbeddedIO : BOOL; (*I/O Status Function*) q_IOStatus : LOCAL_IO_GEN_STATUS; END_VAR </pre>



Step	Action
3	<p>ST program: In the lower part of the ST editor, implement the following program:</p> <pre> (*First Mast Cycle Functions*) q_xIsFirstMastCycle := IsFirstMastCycle(); IF q_xIsFirstMastCycle THEN q_xIsFirstMastWarmCycle := IsFirstMastWarmCycle(); q_xIsFirstMastColdCycle := IsFirstMastColdCycle(); END_IF (*Firmware Version Function*) q_FirmwareVersion := GetFirmwareVersion(); (*Sets each data member of the Firmware Version into a separate variable*) v_dwFwVersion := q_FirmwareVersion.FwVersion; v_wBootVersion := q_FirmwareVersion.BootVersion; v_wCoProcVersion := q_FirmwareVersion.AsicVersion; (*Hardware Version Function*) q_wHardwareVersion := GetHardwareVersion(); (*Serial Number Function*) q_dwSerialNumber := GetSerialNumber(); (*Battery Functions*) (*Battery Voltage Function*) q_wBatteryLevel := GetBatteryLevel(); (*Disables or re-enables the display of the Low Battery LED indicator (Batt)*) q_wResultInhibitBattLed := InhibitBatLowLed(Inhibit := i_xInhibitBatLowLed); (*Event Functions*) (*Get Events Number Function*) q_dwEventNumber := GetEventsNumber(); (*Reset Events Number Function*) IF v_xResetEventsNumber THEN q_xResetEventsNumber := ResetEventsNumber(); v_xResetEventsNumber := FALSE; END_IF (*Last Stop Cause Function*) q_LastStopCause := GetLastStopCause(); (*Boot Project Status Function*) q_BootProjectStatus := GetBootProjectStatus(); (*Short-Circuit on Embedded Outputs Function*) q_wShortCutStatus := GetShortCutStatus(); (*Expansion Bus Status Function*) (*Expansion bus configuration diagnostic*) q_wRightBusStatusGen := GetRightBusStatus(Mask := RIGHTBUS_GET_STATUS.RIGHTBUS_GET_GEN_STATUS); (*Expansion bus Module 1 diagnostic*) i_ExpansionTested := RIGHTBUS_GET_STATUS.RIGHTBUS_GET_STATUS1; q_wRightBusStatus := GetRightBusStatus(Mask := i_ExpansionTested); (*Controller I/O Generic Diagnostic Function*) q_wPlcFault := GetPlcFault(); v_xErrorIOExpansionBus := NOT q_wPlcFault.0; v_xErrorEmbeddedIO := NOT q_wPlcFault.1; (*I/O Status Function*) q_IOStatus := GetLocalIOStatus(Mode := LOCAL_IO_GET_STATUS.LOCAL_IO_GET_GEN_STATUS); </pre>

8. Running the Example

8.1. MAST Task Configuration


Step	Action
1	<p>In the Devices tree view:</p> <ul style="list-style-type: none"> ➤ Expand the contents of the M238_Controller (TM238LFDC24DT) item. ➤ Double-click on the MAST task of the Task Configuration item. ➤ Click on the Add POU command. 


Step	Action
2	<p>In the Input Assistant window that appears:</p> <ul style="list-style-type: none"> ➤ Select your program. <p>In the following picture, the CFC program described in <i>CFC Program</i> (see page 27), PLC_Diag_CFC, is selected:</p>
3	<p>Click on OK.</p> <p>This adds the selected POU to the list of programs run by the MAST task of the controller.</p>






8.2. Downloading the Example to the Controller

The steps listed in the following table describe how to download the example to the Logic Controller. If needed, please refer to the SoMachine online help for further information on these steps: search for **Communication Settings**.

Step	Action
1	Connect the USB programming cable between your PC and the M238 Controller. Please refer to <i>Hardware Installation</i> (see page 16), for the reference and usage of this cable.
2	In the Devices tree view, double-click on the M238_Controller (TM238LFDC24DT) item to open its configuration panel.
3	<p>In the Communication Settings tab of this panel.</p> <ul style="list-style-type: none"> ➤ Click on the Gateway-1 node ➤ Click on the Scan network button <p>If the controller is switched on and connected to your PC with the USB programming cable, it will be detected by SoMachine as shown below:</p>  <p>In this example, the TM238LFDC24DT SN 015342 controller has been detected.</p>


Step	Action
4	<p>Select this controller's node and click on the Set active path button.</p>  <p>This will show SoMachine the way to reach your controller.</p> <p>Option: Uncheck the <input type="checkbox"/> Secure online mode box to avoid validation messages during future online modifications.</p> <p>Note: The firmware version of your controller is displayed as the Target Version.</p>
5	<p>The following window will appear and ask you to confirm your choice:</p> <ul style="list-style-type: none"> ➤ Read the hazard message; ➤ Press on both <Alt> and <F> keys to validate your choice and close this window; ➤ Or, click on the Cancel button if you can not comply with the statements in the hazard message. 

8. Running the Example



Step	Action
6	Click on the  Login button of the toolbar to establish a connection from SoMachine to the controller.
7a	<p>If you download the current project to the controller for the first time and if there is no project on the controller, the following window appears:</p>  <p>Click on Yes to download the Application software to the controller.</p>
7b	<p>If you download the current project to the controller for the first time and if there is another project on the controller, the following window appears:</p>  <p>Click on Yes to download the Application software to the controller.</p>
7c	<p>If you already have downloaded the current project to the controller, the following window appears if you have brought new modifications to this project:</p>  <p>➤ Select the <input checked="" type="radio"/> Login with download choice.</p> <p>Click on OK to download the Application software to the controller.</p>
7d	If you already have downloaded the current project to the controller, the connection is immediate if you brought no modification to this project.
8	<p>Wait for the completion of the download operation.</p> <p>Once it is finished, the status bar of SoMachine displays the state of the controller: </p>
9	<p>Click on the  Start button of the toolbar to run the Application software on the controller.</p> <p>The state of the controller switches from  to </p>


8.3. Running the Example on the Controller

The steps listed in the following table describe how to use the example, once it has been downloaded to the controller.


Step	Action
1	<p>In the Devices panel, double-click on your PLC_Diag program to open it (e.g. PLC_Diag_CFC if you previously selected this program as the program run by the MAST task of your controller).</p> <p>This command opens the program in the central panel of SoMachine; the online values of the variables used by this program are also displayed, as shown below:</p> 
2	<p>Detecting the first cycle of the MAST task using the IsFirstMastCycle , IsFirstMastWarmCycle and IsFirstMastColdCycle Functions:</p> <p>In this example, these three Functions are used in the following manner:</p> <ul style="list-style-type: none"> • The IsFirstMastCycle Function is continuously called to detect the first cycle of the MAST task. This Function updates the <code>q_xIsFirstMastCycle</code> variable: it is set to TRUE only during the first cycle of the MAST task, then it is reset to FALSE. • The IsFirstMastWarmCycle Function is only called during the first cycle of the MAST task (the previous <code>q_xIsFirstMastCycle</code> variable is used to enable or disable its call). This Function updates the <code>q_xIsFirstMastWarmCycle</code> variable: it is set to TRUE if the controller started in warm start mode. • Likewise, the IsFirstMastColdCycle Function is only called during the first cycle of the MAST task. This Function updates the <code>q_xIsFirstMastColdCycle</code> variable: it is set to TRUE if the controller started in cold start mode.

8. Running the Example

Step	Action
	<p>To test these functions, proceed as follows:</p> <ul style="list-style-type: none">➤ Check that the value of <code>q_xIsFirstMastWarmCycle</code> is equal to <code>FALSE</code>.➤ Check that the value of <code>q_xIsFirstMastColdCycle</code> is equal to <code>TRUE</code>: the controller started in cold start mode (normal behavior after a download operation).➤ Click on the  Stop button of the toolbar to stop the Application software on the controller.➤ In the Online menu, click on the Reset warm command to force a warm start of the controller.  <p>The screenshot shows the 'Online' menu with the following items: Login (Alt+F8), Logout (Ctrl+F8), Create boot application, USB Mass Storage..., Remote connection..., Multiple Download..., Download, Online Change, Source download to connected device, Start (F5), Stop (Shift+F8), Reset warm (highlighted), Reset cold, and Reset origin.</p> <ul style="list-style-type: none">➤ Click on Yes to confirm this command.  <p>The dialog box titled 'SoMachine' contains a question mark icon and the text: 'Do you really want to perform the operation 'Reset warm?'. There are 'Yes' and 'No' buttons at the bottom, with the 'Yes' button highlighted.</p> <ul style="list-style-type: none">➤ Click on the  Start button of the toolbar to run the Application software on the controller.➤ Check that the value of <code>q_xIsFirstMastWarmCycle</code> is equal to <code>TRUE</code>: the controller started in warm start mode because of the Reset warm command.➤ Check that the value of <code>q_xIsFirstMastColdCycle</code> is equal to <code>FALSE</code>. <p>For a description of the cold start and warm start modes, please refer to the SoMachine online help: search for Reset Warm, Reset Cold, or Commanding State Transitions.</p>

Step	Action
3	<p>Getting the controller's firmware, boot, coprocessor, and hardware versions using the <code>GetFirmwareVersion</code> and <code>GetHardwareVersion</code> Functions:</p> <p>To test these functions, proceed as follows:</p> <ul style="list-style-type: none"> ➤ In the Debug/Watch menu, execute the Hexadecimal command to switch the numeric display mode from Decimal to Hexadecimal.  <p>The screenshot shows the 'Debug/Watch' menu with the 'Display Mode' option selected. A submenu is open showing 'Binary', 'Decimal' (checked), and 'Hexadecimal' (highlighted by the mouse cursor).</p> <ul style="list-style-type: none"> ➤ Split the value of the <code>v_dwFwVersion</code> DWORD variable (32-bit) into four BYTE data (4 × 8-bit). ➤ Convert each of these bytes in Decimal to get the controller's firmware version. An example is given below: <pre> v_dwFwVersion16#02001E0D 4-byte data16#02 / 16#00 / 16#1E / 16#0D 4-byte version.....2 / 0 / 30 / 13 Firmware version.....v2.0.30.13 </pre> <p>Note: Compare this version with the firmware version displayed when you select your controller's node, as shown in <i>Downloading the Example to the Controller</i> (see page 51). They are identical.</p> ➤ Split the value of the <code>v_wBootVersion</code> WORD variable (16-bit) into two BYTE data (2 × 8-bit). ➤ Convert each of these bytes in Decimal to get the controller's boot version. An example is given below: <pre> v_wBootVersion16#0104 2-byte data16#01 / 16#04 2-byte version.....1 / 4 Boot versionv1.4 </pre>

8. Running the Example

Step	Action
	<ul style="list-style-type: none"> ➤ The value of <code>v_wCoProcVersion</code> indicates the controller's coprocessor version. Example: 16#0058. ➤ The value of <code>q_wHardwareVersion</code> indicates the controller's Hardware Version. Example: 16#0200.
4	<p>Getting the controller's Serial Number using the <code>GetSerialNumber</code> Function:</p> <p>To test this function, proceed as follows:</p> <ul style="list-style-type: none"> ➤ In the Debug/Watch menu, execute the Hexadecimal command to switch back the numeric display mode from Hexadecimal to Decimal.  <ul style="list-style-type: none"> ➤ The value of <code>q_dwSerialNumber</code> indicates the controller's Serial Number. Example: 15342. <p>Note: Compare this value with the Serial Number (notation: "S/N") written on the controller's identification sticker. They are identical. Example: "S/N :015342".</p>
5	<p>Getting the battery level using the <code>GetBatteryLevel</code> Function:</p> <p>To test this function, proceed as follows:</p> <ul style="list-style-type: none"> ➤ Check the value of <code>q_wBatteryLevel</code>: it is a percentage that ranges from 0 (empty battery) to 100 (fully charged battery). <p>Note: If no external backup battery (ref. TSX PLP 01) has been installed on your controller, then <code>q_wBatteryLevel</code> is equal to 0.</p>

Step	Action
6	<p data-bbox="261 215 1362 248">Disabling and re-enabling the Batt LED using the <code>InhibitBatLowLed</code> Function:</p> <p data-bbox="261 266 1422 300">If an external backup battery is installed on your controller, remove it as instructed below:</p> <ul style="list-style-type: none"> <li data-bbox="285 318 1362 389">➤ Click on the  Logout button of the toolbar to disconnect SoMachine from the controller. <li data-bbox="285 407 635 441">➤ Power off the controller. <li data-bbox="285 459 1362 530">➤ Read the hazard message given in the Installing and Replacing the External backup battery section of the <i>Modicon M238 Logic Controller Hardware Guide</i>. <li data-bbox="285 548 1385 620">➤ Remove the external backup battery as instructed in this very same section of the <i>Modicon M238 Logic Controller Hardware Guide</i>. <li data-bbox="285 638 635 672">➤ Power on the controller. <li data-bbox="285 689 1286 761">➤ Click on the  Login button of the toolbar to establish a connection from SoMachine to the controller. <p data-bbox="261 779 786 813">To test this function, proceed as follows:</p> <ul style="list-style-type: none"> <li data-bbox="285 831 995 864">➤ Check that the red Batt LED of the controller is ON. <li data-bbox="285 882 1230 916">➤ Change the value of <code>i_xInhibitBatLowLed</code> from FALSE to TRUE. <li data-bbox="285 934 1011 967">➤ Check that the red Batt LED of the controller is OFF. <li data-bbox="285 985 1414 1057">➤ Check that the value of <code>q_wResultInhibitBattLed</code> is equal to TRUE (operation successful). <li data-bbox="285 1075 1230 1108">➤ Change the value of <code>i_xInhibitBatLowLed</code> from TRUE to FALSE. <li data-bbox="285 1126 995 1160">➤ Check that the red Batt LED of the controller is ON. <li data-bbox="285 1178 1414 1249">➤ Check that the value of <code>q_wResultInhibitBattLed</code> is equal to TRUE (operation successful). <p data-bbox="261 1267 1370 1339">If you previously removed an external backup battery from your controller, install it as instructed below:</p> <ul style="list-style-type: none"> <li data-bbox="285 1357 735 1391">➤ Click on the  Logout button. <li data-bbox="285 1408 635 1442">➤ Power off the controller. <li data-bbox="285 1460 1422 1532">➤ Install the external backup battery as instructed in the Installing and Replacing the External backup battery section of the <i>Modicon M238 Logic Controller Hardware Guide</i>. <li data-bbox="285 1550 635 1583">➤ Power on the controller. <li data-bbox="285 1601 715 1635">➤ Click on the  Login button.

8. Running the Example

Step	Action
7	<p data-bbox="261 210 1362 282">Reading and resetting the number of events using the <code>GetEventsNumber</code> and <code>ResetEventsNumber</code> Functions:</p> <p data-bbox="261 300 826 331">To test these functions, proceed as follows:</p> <ul data-bbox="284 349 1422 636" style="list-style-type: none"><li data-bbox="284 349 1422 421">➤ Using the push-button connected to the I0 fast input of the controller, generate a few pulses on this input.<li data-bbox="284 434 1422 506">Note: This push-button is described in <i>Wiring the Controller's I0 Fast Input</i> (see page 24).<li data-bbox="284 519 1422 591">➤ Observe the value of <code>q_dwEventNumber</code>: each pulse increased this value by two (+1 for the rising edge of the pulse and +1 for its falling edge).<li data-bbox="284 604 1422 636">➤ Set the <code>v_xResetEventsNumber</code> variable to TRUE. <p data-bbox="261 654 1410 725">Since this variable is connected to the EN (enable) pin of the ResetEventsNumber Function, this Function is now called.</p> <p data-bbox="261 739 1315 770">Then, this variable resets the <code>v_xResetEventsNumber</code> variable to FALSE.</p> <p data-bbox="261 784 1430 994">Note: In the case of the CFC program described in <i>CFC Program</i> (see page 27), this variable is transmitted through the ENO (enable output) pin before resetting <code>v_xResetEventsNumber</code>. This is intended to obtain an execution order in which the ResetEventsNumber Function is called before the reset of <code>v_xResetEventsNumber</code>, provided that the Order By Data Flow command (see page 33) has been performed.</p> <p data-bbox="261 1008 1410 1079">Because <code>v_xResetEventsNumber</code> is reset, the ResetEventsNumber Function is called during only one task cycle.</p> <ul data-bbox="284 1093 1075 1124" style="list-style-type: none"><li data-bbox="284 1093 1075 1124">➤ Check that the value of <code>q_dwEventNumber</code> is equal to 0.
8	<p data-bbox="261 1151 1315 1182">Reading the cause of the last stop using the <code>GetLastStopCause</code> Function:</p> <p data-bbox="261 1200 788 1232">To test this function, proceed as follows:</p> <ul data-bbox="284 1249 1043 1599" style="list-style-type: none"><li data-bbox="284 1249 1043 1281">➤ Click on the  Stop button of the toolbar.<li data-bbox="284 1308 1043 1339">➤ Click on the  Start button of the toolbar.<li data-bbox="284 1366 1043 1438">➤ Check that the value of <code>q_LastStopCause</code> is equal to <code>STOP_FROM_STOP_REQUEST</code>.<li data-bbox="284 1451 1043 1482">➤ Click on the  Logout button of the toolbar.<li data-bbox="284 1509 1043 1541">➤ Power off the controller.<li data-bbox="284 1554 1043 1585">➤ Wait during two seconds. <p data-bbox="261 1603 1430 1747">Note: Since the M238 controller has been designed to continue operation during short transient power interruptions, it is necessary to wait for the complete shutdown of the controller. Please refer to the AC Power Supply Specifications section of the <i>Modicon M238 Logic Controller Hardware Guide</i> for detailed information.</p> <ul data-bbox="284 1760 1410 1904" style="list-style-type: none"><li data-bbox="284 1760 1410 1792">➤ Power on the controller.<li data-bbox="284 1805 1410 1836">➤ Click on the  Login button of the toolbar.<li data-bbox="284 1863 1410 1895">➤ Check that the value of <code>q_LastStopCause</code> is equal to <code>STOP_FROM_POWER_FAIL</code>.

Step	Action
9	<p>Reading the status of the boot project using the <code>GetBootProjectStatus</code> Function:</p> <p>To test this function, proceed as follows:</p> <ul style="list-style-type: none"> ➤ Check that the value of <code>q_BootProjectStatus</code> is equal to <code>VALID_BOOT_PROJECT</code>.
10	<p>Reading the short-circuit (or overload) diagnostic on the controller's embedded outputs using the <code>GetShortCutStatus</code> Function:</p> <p>To test this function, proceed as follows:</p> <ul style="list-style-type: none"> ➤ Check that the value of <code>q_wShortCutStatus</code> is equal to 0: bits 0, 1, and 2 of this WORD are equal to FALSE because there is no short-circuit on the controller's embedded outputs. <p>Note: Please refer to the Regular Output Wiring Diagram (or Transistor Output Wiring Diagram) and Short-circuit or Over-current on Outputs sections of the <i>Modicon M238 Logic Controller Hardware Guide</i>. These sections contain several hazard messages and instructions that you must read concerning the M238 controller's protections against short-circuits and overloads.</p>
11	<p>Reading the status of the controller's expansion bus using the <code>GetRightBusStatus</code> Function:</p> <p>To test this function for a configuration diagnostic of the expansion bus (<code>RIGHTBUS_GET_GEN_STATUS</code>), proceed as follows:</p> <ul style="list-style-type: none"> ➤ Check the value of <code>q_wRightBusStatusGen</code>: it is equal to 0 (bits 1 to 7 are equal to FALSE) because there is no expansion bus configuration mismatch. <p>Note: In the case of this example, no TM2 module has been configured in SoMachine and no TM2 module has been physically installed on the controller.</p> <p>To test this function for a diagnostic of the first (analog) expansion module (<code>RIGHTBUS_GET_STATUS1</code>), proceed as follows:</p> <ul style="list-style-type: none"> ➤ Check the value of <code>q_wRightBusStatus</code>: it is equal to 0 because no diagnostic is available for this analog expansion module. <p>Note: In the case of this example, no analog module has been physically installed on the controller.</p>
12	<p>Detecting errors on the controller I/O using the <code>GetPlcFault</code> Function:</p> <p>To test this function, proceed as follows:</p> <ul style="list-style-type: none"> ➤ Check the value of <code>v_xErrorIOExpansionBus</code> (bit 0 of <code>q_wPlcFault</code>): it is equal to FALSE because the I/O expansion bus is healthy. ➤ Check the value of <code>v_xErrorEmbeddedIO</code> (bit 1 of <code>q_wPlcFault</code>): it is equal to FALSE because the embedded I/O of the controller are healthy. <p>Note: As pointed out in the SoMachine online help, these two data could be used as conditions for calling the <code>GetRightBusStatus</code> and the <code>GetLocalIOStatus</code> Functions. Please refer to the SoMachine online help: search for <code>GetPlcFault</code>.</p>
13	<p>Reading the status of the controller's embedded I/O using the <code>GetLocalIOStatus</code> Function:</p> <p>To test this function, proceed as follows:</p> <ul style="list-style-type: none"> ➤ Check the value of <code>q_IOStatus</code>: it is equal to <code>LOCAL_IO_OK</code> because the inputs / outputs of the controller are operational.