

## FX3U-□M□-E□. Corriente residual a 24V CC

### Para FX3U-16M y FX3U-32M

Salidas										
Salidas añadidas	40	25								
	32	100	50	0						
	24	175	125	75	25					
	16	250	200	150	100	50	0			
	8	325	275	225	175	125	75	25		
	0	400	350	300	250	200	150	100	50	0
	0	8	16	24	32	40	48	56	64	Entradas

Entradas añadidas

### Para FX3U-48M, FX3U-64M, FX3U-80M y FX3U-128M

Salidas														
Salidas añadidas	64	0												
	56	75	25											
	48	150	100	50	0									
	40	225	175	125	75	25								
	32	300	250	200	150	100	50	0						
	24	375	325	275	225	175	125	75	25					
	16	450	400	350	300	250	200	150	100	50	0			
	8	525	475	425	375	325	275	225	175	125	75	25		
0	600	550	500	450	400	350	300	250	200	150	100	50	0	
	0	8	16	24	32	40	48	56	64	72	80	88	96	Entradas

Entradas añadidas

### Ejemplos de configuración.

Añadiendo 16 entradas y 16 salidas a FX3U-16/32M, la corriente residual a 24V CC es 150mA.

Añadiendo 32 entradas y 16 salidas a FX3U-48~128M, la corriente residual a 24V CC es 250 mA.