




Twido and LEXIUM05/CPD17 via Pulse-Direction-Interface

Control of Speed and Position without using a Field bus



This document describes how to build a small position module using a TWIDO PLC and LEXIUM05/CPD17 drive including the wiring and a program example.

Designed 07.06.2005 by

Patrick Friedmann

Berger Lahr GmbH

Customer Support Center - Technical Support

Gewerbestraße 9

D-77749 Hohberg-Niederschopfheim.

Tel.: +49 7808 / 943-235

Fax: +49 7808 / 946-58 235

E-Mail: <mailto:patrick.friedmann@berger-lahr.com>




BERGER LAHR



Typical Application: Pusher on a conveyor

A pusher moves material on a conveyor. The positions are defined with limit switches. The PLC stops the movement when the Pusher reaches the limit switches.

- Positions can only be adjusted by moving the limit switches
- Speed control with using a frequency inverter: Speed is only changeable between fixed values or continuous with additional hardware (analogue PLC outputs)
- Speed control without using a frequency inverter is not possible (exception: pole-changing motor)
- Complex hardware installations






Solution with TWIDO, USIC and LEXIUM05/CPD 17

LEXIUM05/CPD17 is a small drive with a high performance. It can be used as an “electronic gear” via the pulse/direction interface. One pulse at the interface moves the motor one increment.

TWIDO is a small PLC with fast transistor outputs. Its configuration tool provides a standard function block that generates a sequence of pulses.

USIC converts the PLC output signals to a pulse/direction signal.


- Positions can be adjusted in the PLC program (optional with HMI)
- Speed control on the drive, set values from the PLC (optional with HMI)
- **No field bus needed!**





Components

TWIDO Modular TWDLMDA20RT




Label	Description
1	Hinged lid
2	Expansion connector
3	Analog potentiometer
4	Serial port 1
5	Cartridge covers
6	24 VDC power supply terminals
7	Analog voltage input connector
8	LEDs
9	I/O terminals
10	Communication connector

16 Digital Inputs Sink/Source
 8 Digital Outputs (6 Relays and 2 Transistor source)
 Expandable with 7 additional modules



USIC (Universal Signal Interface Converter) GEA3EC001



The USIC (Universal Signal Interface Converter) is an interface adapter, which is used as a universal adapter for a pulse/direction interface to a PLC.



LEXIUM05/CPD17 Drive




A universal drive with:

- Auto tuning on board, manual optimisation of the control loop with PS 2
- +/- 10V analogue signal interface
- Pulse/direction and A/B signal interface
- Field bus interface CANopen DS402 and ModBus RTU, optional (in the future): Profibus DP
- Safety stop integrated in the drive
- 4 sizes
- Standard motors & drives combination are defined



Wiring


TWIDO



I0	Run CPU	Q0	Pulses
I1	Step mode/ continuous mode	Q2	Direction
I2	Start	Q3	Enable
I3	Enable		
I4	Direction		




USIC






Connection cable between USIC and LEXIUM05/CPD17






LEXIUM05/CPD17

Overview





CN1	Pin 11-14	Analogue Inputs	here not used
CN1	Pin 21-23	Can Open	here not used
CN1	Pin 31	Output "No Fault"	optional
	Pin 32	Output for HBC holding break controller	optional
	Pin 33	not used	
	Pin 34	Input Reset	optional
	Pin 35	Input Enable	here not used
	Pin 36	Input /Halt (Function Stop)	must be connected
	Pin 37	Input /Safe_Disable_A (Emergency Stop)	must be connected
	Pin 38	Input /Safe_Disable_B (Emergency Stop)	must be connected
	Pin 39	24V for Pin 37+38 if not used	optional
CN2	Connection of motor sensor		
CN3	Pin 41+42	0VDC	must be connected
	Pin 43+44	24VDC	must be connected
CN4	Connection to PC or peripheral control terminal		
CN5	pulse/direction interface		connected with -X3


Connection of motor phases and supply voltages depends on the size of the drive. Use the manuals!



Implementation

Twido

Twidosoft, the configuration software tool, provides two impulse generator function blocks. They allow generating a number of pulses with several frequencies.



<u>Function</u>	<u>Object</u>	<u>Description</u>
Time base	T _B	0,142ms, 0,57ms, 10ms or 1s
Pre-adjustable period	%PLS.P	Basic setting
Number of pulses	%PLS.N %PLS.ND	defines the number of pulses. If %PLS=0 an unlimited number of pulses is generated
Adjustable	Yes/No	If Yes the parameter %PLS.P is adjustable from the program
Start	IN	Starts the generation of pulses
Reset	R	Resets the outputs and the number of the generated pulses
Pulses active	Q	Pulse generation is active
Finished	D	Pulse generation is ready

The function block %PLS0 uses the output Q0.0 as a default setting. The relation between T_{on}/T_{off} is always 50%.



In the most cases it will be helpful to use the smallest Time base.

$$T_B = 0,14ms$$

Then %PLS.P is adjustable between 1 and 255. That leads to the minimum and maximum frequencies:

$$f_{\min} = \frac{1}{255 \cdot 0,142 \cdot 10^{-3}s} = 27,6Hz$$

$$f_{\max} = \frac{1}{1 \cdot 0,142 \cdot 10^{-3}s} = 7042,3Hz = \frac{1}{0,142 \cdot 10^{-3}s} \cdot \frac{60s}{\min} = 422.535 \min^{-1} = 422.535 \frac{Inc}{\min}$$

The resulting speed on the motor depends also on the adjusted gear factor GF and the internal resolution IR of the drive. The internal resolution is the number of increments for one revolution of the motor. For the LEXIUM05/CPD17 the internal resolution is:

$$IR = 131072Inc$$

The resulting speeds are:

$$n_{\max} = \frac{f_{\max} \cdot GF}{IR} = \frac{422535 \frac{Inc}{\min} \cdot GF}{131072Inc}$$


$$n = \frac{n_{\max}}{\%PLS0.P}$$



Now an example. The maximum speed should be 6000min^{-1} . Then the gear factor is

$$GF = \frac{n_{\max} \cdot IR}{f_{\max}} = \frac{6000 \frac{1}{\text{min}} \cdot 131072 \text{Inc}}{422535 \frac{\text{Inc}}{\text{min}}} = 1861,24$$

and the speed is changeable in the steps as shown in the following diagram.




The stroke per revolution of the motor corresponds to

$$U = \frac{IR}{GF} = \frac{131072 \text{Inc}}{1861,24} = 70,4 \text{Inc}$$

That means if the TWIDO generates 70 Pulses, the motor makes about one resolution.



The software is quite easy. Here is an example:



- Input 0.1 changes between step mode and continuous mode.
If %I0.1 is true and a positive flag on %I0.2 TWIDO generates 70 pulses and the motor makes about one revolution.
If %I0.1 is false and a positive flag on %I0.2 TWIDO generates an endless number of pulses and the motor is turning continuously.
- Input 0.2 a positive flag on %I0.2 starts the generation of pulses.
- Input 0.3 enables the drive
- Input 0.4 switches the direction of the motor

- %MW10 SET SPEED is the set value of speed. Here it is changeable in the animation table.



LEXIUM05/CPD 17

The commissioning of the drive is also very simple. With the first time of switch on the power supply of the drive with the connected motor, the drives reads automatically the motor data from the hyperface sensor (motor sensor).

Then it is necessary to do the “First set up” via the integrated HMI.





Figure 7.2 HMI and decentralised control terminal

- (1) LEDs for CANopen
- (2) ESC:
 - exit a menu or parameter
 - return from the displayed to the last saved value
- (3) ENT:
 - call a menu or parameter
 - save the displayed value to EEPROM
- (4) Down arrow:
 - switch to next menu or parameter
 - reduce the displayed value
- (5) Up arrow:
 - switch to previous menu or parameter
 - increase the displayed value
- (6) Red LED on: DC bus under voltage
- (7) Status display
- (8) Quick Stop (Software Stop)
- (9) Fault Reset (Continue)
- (10) No function

2 LEDs show the status of the CANopen state machine as per the CANopen standard DR 303-3.



The device control mode (dEUC) is IO-mode, and the IO-mode is electronic gear (GEAr). With the parameter IO Logical level it is possible to adjust a positive or negative logic. After the saving of the parameters the drive must be switched off and on again.

Only two parameters more must be adjusted, the configuration of the pulse/direction interface and the gear factor. That could be done via the HMI or with Powersuite, a comfortable programming tool.



PowerSuite - Test1 - Test1

Suchen

- Alle Parameter
 - First Setup
 - IO
 - Configuration
 - Analog
 - Ballast
 - Brake
 - Drivecom
 - ESIM
 - HMI
 - IO
 - Position
 - PWM
 - Ramp
 - Supervision
 - Settings
 - Analog
 - Controller
 - Limitations
 - Postinterface
 - Standstill
 - Datasheet
 - Ballast internal
 - Device
 - Motor
 - Power Amplifier
 - Communication
 - CANopen
 - Modbus
 - Motion
 - electr Gear
 - Homing
 - Jog

Code	Bezeichnung	Minimum value	Maximum value	Wert	Standardwert	Logische Adresse	Menü
A1IS	ANA1_j_scale	-300 Apk	300 Apk	3.00 Apk	3.00 Apk	8198	
A1NS	ANA1_n_scale	-30000 U/min	30000 U/min	3000 U/min	3000 U/min	8454	
A1WN	ANA1_w_in	0 mV	1000 mV	0 mV	0 mV	2322	
A2LC	ANA2_l_max	0 Apk	300 Apk	3.00 Apk	0.00 Apk	4632	
A2LN	ANA2_n_max	500 U/min	30000 U/min	3000 U/min	0 U/min	4634	
A2MO	ANA2LimMode	-	-	none	none	4630	
ACC	RAMPacc	30 U/min*s	3e+006 U/min*s	600 U/min*s	600 U/min*s	1556	
ASH	IO_AutoEnable	-	-	off	off	1292	
BALL	BALInt_ext	-	-	Internal Ballast	Internal Ballast	1298	
BALP	BALExt_P	1 W	32767 W	30 W	30 W	1316	
BALR	BALExt_R	0.01 Ohm	327.67 Ohm	47.00 Ohm	47.00 Ohm	1318	
BALT	BALExt_ton	1 ms	5000 ms	11 ms	11 ms	1314	
CHOP	PWM_fChop	-	-	8 kHz	48 Hz	1308	
COAD	CANadr	1	127	127	127	5892	
COBD	CANbaud	-	-	125KB	125KB	5894	
CURRFOL	CTRL_TAUref	0 ms	4 ms	0.50 ms	0.50 ms	4640	
DCST	PA_U_minStopDC	0.1 V	2000 V	200.0 V	0.0 V	4116	
DEC	RAMPdecel	750 U/min*s	3e+006 U/min*s	750 U/min*s	750 U/min*s	1558	
DEVIC	DEVcmdinterf	-	-	IODevice	none	1282	
DINV	POSdirOrRotat	-	-	clockwise	clockwise	1560	
ESIS	ESIMscale	-	-	4096	4096	1322	
FAC	SPV_FIL_AC	-	-	ErrorClass2	ErrorClass2	1300	
FFDI	SPV_FIL_pDiff	-	-	ErrorClass3	ErrorClass3	1302	
GDEN	GEARdenom	1	2.14748e+009	1	1	9734	
GDIR	GEARdir_enabl	-	-	both	both	9738	
GNLUM	GEARnum	-2.14748e+009	2.14748e+009	1871	1	9736	
GRES	GEARratio	-	-	GearFactor	GearFactor	9740	
HNFL	Hm_n_out	1 U/min	3000 U/min	6 U/min	6 U/min	10250	
HOHO	HmDisusr	1 usr	2.14748e+009 usr	200 usr	200 usr	10254	
HOMP	HmOutdisusr	0 usr	2.14748e+009 usr	0 usr	0 usr	10252	
HOSN	Hm_n	1 U/min	13200 U/min	60 U/min	60 U/min	10248	
HRAP	Hmp_homeusr	-2.14748e+009 usr	2.14748e+009 usr	0 usr	0 usr	10262	
HSOL	Hmsrchdisusr	0 usr	2.14748e+009 usr	0 usr	0 usr	10266	
IOM	M_I_0	0.01 Apk	327.67 Apk	4.24 Apk	0.00 Apk	3366	
I2DT	M_I2t	1 ms	32767 ms	2500 ms	0 ms	3362	
IMAX	CTRL_l_max	0 Apk	15.56 Apk	15.56 Apk	0.00 Apk	4610	
IMHA	LIM_l_maxHalt	0 Apk	15.56 Apk	15.56 Apk	0.00 Apk	4364	
IMGS	LIM_l_maxGTP	0 Apk	15.56 Apk	15.56 Apk	0.00 Apk	4362	

Befehl: Aktiv / Inaktiv
 CURref: Ein / Aus
 CUR_J_target [A]: 0 (Min: -15.56, Max: 15.56)
 Test Run / Test Stop
 Enable: Ein / Aus
 POWER ENABLED (6) Op Enable
 Reset

Elektronisches Getriebe
 HALT=Inaktiv
 S.Fault= 0x0000
 Lokale Steuerung
 DEVcmdinterf=IODevice

_D_refusr=32514643usr
 _p_actusr=32514642usr
 _n_ref=0 U/min
 _n_act=0 U/min
 _ldq_act=0.03 Apk

Verbunden de

Designed 07.06.2005 by

Patrick Friedmann
Berger Lahr GmbH
 Customer Support Center - Technical Support
 Gewerbestraße 9
 D-77749 Hohberg-Niederschopfheim.
 Tel.: +49 7808 / 943-235
 Fax: +49 7808 / 946-58 235
 E-Mail: <mailto:patrick.friedmann@berger-lahr.com>

